



870-7419546 ~ TOLL FREE: 800-369-4131
info@stullfeeders.com www.stullfeeders.com

UNIVERSAL TRAILER



TRAILER ASSEMBLY - Page 1



Step 1

-STEP 1-USE 3/8X1" BOLTS FOR MOUNTING
CROSS MEMBER TO TRIANGLE PLATES



Step 2

-STEP 2-USE 3/8X2 BOLTS FOR MOUNTING AXLE
TO TRIANGLE PLATES



Step 3

-STEP 3-USE 3/8X1" BOLTS TO MOUNT ANGLE
IRON TO TRIANGLE PLATE



Step 4

-STEP 4-USE 3/8X5" BOLTS FOR MOUNTING
SQUARE PIPE OVERLAP FOR TONGUE



Step 5

-STEP 5-INSTALL HUB ASSEMBLY KITS ON BOTH
AXLES(USE *HIGH TEMP BEARING GREASE FOR
PACKING BEARINGS*)



Step 6

-STEP 6-INSTALL TIRE ON EACH HUB USING LUG NUTS
PROVIDED WITH HUB KITS

TRAILER ASSEMBLY - Page 2



-STEP 7&8-USE GOLD
3/8X3" BOLTS TO MOUNT
COUPLER AND JACK TO
TONGUE



Step 7

****USE SILVER 3/8X3" BOLTS TO MOUNT JACK TO BACK
END OF TRAILER
**OPTIONAL TRAILER JACK ASSEMBLY ON BACK
NOT SHOWN****

Step 8



Step 9



Step 10



Step 11



Step 12

**Trailer must be decked with plywood and
feeder bolted through plywood and trailer on
corners. (Plywood NOT INCLUDED)**